



XS WIRELESS 1

Quick Guide | Kurzanleitung | Guide rapide | Guida rapida | Guía de inicio rápido | Guia rápido | Beknopte handleiding | Krótka instrukcja obsługi | Snabbguide | Kort vejledning | Pikaohje | Γρήγορος οδηγός | Kisa Kilavuz | Краткая инструкция | 快速指南 | 快速使用指南 | クイックガイド | 요약 설명서

In the box	Vocal Sets		Instrument Sets		Lavalier Set	Headmic Set
XS WIRELESS 1	XSW 1-825	XSW 1-835	XSW 1-CI1	XSW 1-908	XSW 1-ME2	XSW 1-ME3
EM-XSW 1	•	•	•	•	•	•
NT 12-5CW	•	•	•	•	•	•
SKM 825-XSW	•	•	•	•	•	•
MZQ 1	•	•	•	•	•	•
SKM 835-XSW	•	•	•	•	•	•
SK-XSW	•	•	•	•	•	•
e 908T	•	•	•	•	•	•
ME 2-2	•	•	•	•	•	•
ME 3-II	•	•	•	•	•	•
CI 1-N	•	•	•	•	•	•
2 x AA LR6 1.5 V	•	•	•	•	•	•

Battery

Low Battery

~ 10 h
~ 7 h
~ 3 h
Low Batt

Setup

Line Mic
XLR-3
6.3 mm

EU US UK AU CN KOR

ME 2-2
e 908T
ME 3-II
CI 1-N

On/off

1s on
3s off

Display

EM-XSW 1

Bank 1...8 Channel 0...9

Sensitivity Sync Low battery

Volume

0...9

0 1 2 3 4 5 6 7 8 9

Mute

Audio on
Audio off

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany, www.sennheiser.com
Printed in Germany, Publ. 02/17, 571312/A02

SENNHEISER

Change frequency

Automatically/Scan

Manually

Bank Channel

Sync

Sensitivity

Level

Multichannel

Bank 1...8
Ch. 0...9

Bank	CH.	Bank	CH.	Bank	CH.	Bank	CH.	
2	3	2	4	2	5	2	6	✓
1	1	1	2	1	3	1	8	✓
2	3	1	3	4	7	8	9	✗
2	3	2	3	2	3	2	3	✗

max. 10 ch.

ME 2-II

ME 3-II

Min. distance

SKM

Guitar pickup

Squelch

min. SQ

max. SQ

